
CISCO Academy

Packet Tracer – Create a Simple Network Using Packet Tracer

Topology



Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
PC	Ethernet0	DHCP		192.168.0.1
Wireless Router	LAN	192.168.0.1	255.255.255.0	
WRT300N	Internet	DHCP		
Cisco.com Server	Ethernet0	208.67.220.220	255.255.255.0	
Laptop	Wireless0	DHCP		

Objectives

- Part 1: Build a Simple Network in the Logical Topology Workspace
- Part 2: Configure the Network Devices
- Part 3: Test connectivity between network devices
- Part 4: Save the File and Close Packet Tracer

Background / Scenario


In this activity you will build a simple network in Packet Tracer from scratch and then save the network as a Packet Tracer Activity File (.pkt).

Part 1: Build a Simple Network in the Logical Topology Workspace

Step 1: Launch Packet Tracer.

a. Launch Packet Tracer on your PC or laptop computer

Double click on the Packet Tracer icon on your desktop or navigate to the directory that contains the Packet Tracer executable file and launch Packet Tracer. Packet Tracer should open with a blank default Logical topology workspace as shown in the figure.



Step 2: Build the topology

a. Add network devices to the workspace.

Using the device selection box, add the network devices to the workspace as shown in the topology diagram.

To place a device onto the workspace, first choose a device type from the **Device-Type Selection** box. Then, click on the desired device model from the **Device-Specific Selection** box. Finally, click on a location in the workspace to put your device in that location. If you want to cancel your selection, click the **Cancel** icon for that device. Alternatively, you can click and drag a device from the **Device-Specific Selection** box onto the workspace. b. Add network devices to the workspace.

Using the device selection box, add the network devices to the workspace as shown in the topology diagram

To place a device onto the workspace, first choose a device type from the **Device-Type Selection** box. Then, click on the desired device model from the **Device-Specific Selection** box. Finally, click on a location in the workspace to put your device in that location. If you want to cancel your selection, click the **Cancel** icon for that device. Alternatively, you can click and drag a device from the **Device-Specific Selection** box onto the workspace.

c. Change display names of the nework devices.

To change the display names of the network devices click on the device icon on the Packet Tracer Logical workspace, then click on the **Config** tab in the device configuration window. In the Config tab type the new name of the device into the **Display Name** box as show in the figure.

۲	Wireless Router			_	\times
	Physical Config	G	UI Attributes		
	GLOBAL	^	Global Settings		_
	Settings Algorithm Settings		Display Name Wireless Router		
	INTERFACE Internet				
	LAN				
	Wireless				

d. Add the physical cabling between devices on the workspace

Using the device selection box, add the physical cabling between devices on the workspace as shown in the topology diagram.

The PC will need a copper straight-through cable to connect to the Wireless Router. Select the copper straight-through cable in the Device-Selection box and attach it to the FastEthernet0 interface of the PC and the Ethernet 1 interface of the Wireless Router. Note: Choose the WRT300N for the wireless router.

The Wireless Router will need a copper straight-through cable to connect to the Cable Modem. Select the copper straight-through cable in the Device-Selection box and attach it to the Internet interface of the Wireless Router and the Port 1 interface of the Cable Modem.

The Cable Modem will need a coaxial cable to connect to the Internet cloud. Select the coaxial cable in the Device-Selection box and attach it to the Port 0 interface of the Cable Modem and the coaxial interface of the Internet cloud.

The Interne cloud will need copper straight-through cable to connect to the Cisco.com server. Select the copper straight-through cable in the Device-Selection box and attach it to the Ethernet interface of the Internet cloud and the FastEthernet0 interface of the Cisco.com server.

Part 2: Configure the Network Devices

Step 1: Configure the Wireless Router

a. Create the wireless network on the Wireless Router

Click on the Wireless Router icon on the Packet Tracer Logical workspace to open the device configuration window.

In the Wireless Router configuration window click on the GUI tab to view configuration options for the Wireless Router.

Next, click on the **Wireless** tab in the GUI to view the wireless settings. The only setting that needs to be changed from the defaults is the **Network Name (SSID)**. Here, type the name "HomeNetwork" as shown in the figure.

Wireless-N Broadbar	nd Router						
							ware Version: v0.93.3
Wireless	Setup	Wireless	Security	Access	Wirele Applications	ess-N Broadband Ro Administration	
wireless	Basic Wireless		Wireless Security	Restrictions Wirele	& Gaming as MAC Filter		Vireless Settings
Basic Wireless Settings	Network Mode:			Mixed		Help	
	Natural Nama (CC)	(D).				-	
	Network Name (SSI	ID):		HomeNetwork		_	
	Radio Band:			Auto		-	
	Wide Channel:			Auto		•	
	Standard Channel:			1 - 2.412GHz		•	
	SSID Broadcast:			Enabled	O Disabled		

b. Configure the Internet connection on the Wireless Router

Click on the Setup tab in the Wireless Router GUI.

In the DHCP Server settings verify that the **Enabled** button is selected and configure the static IP address of the DNS server as 208.67.220.220 as shown in the figure.

c. Click on the Save Settings tab.

Physical Config GL	JI Attributes	
Wireless-N Broadband Ro	Juter	
	Wireless-N B	Firmware Version: v0.93.3 roadband Router WRT300N
Setup	Setup Wireless Security Access Applications Ad	ministration Status
	Basic Setup DDNS MAC Address Clone	Advanced Routing
Internet Setup		
Internet	Automatic Configuration - DHCP 💌	Help
Connection type		
Optional Settings	Host Name:	
(required by some internet service	Domain Name:	
providers)	MTU: Visite: 1500	
		-
Network Setup		
Router IP	IP Address: 192 · 168 · 0 · 1	
	Subnet Mask: 255.255.255.0	_
DHCP Server	DHCP	
Settings	Server: Reservation	
	Start IP Address: 192.168.0. 100	
	of Users: 50	
	IP Address Range: 192.168.0. 100 - 149	
	Client Lease Time: 0 minutes (0 means one day	/)
	Static DNS 1: 208 . 67 . 220 . 220	-
	Static DNS 2: 0 . 0 . 0 . 0	-
	Static DNS 3: 0 . 0 . 0 . 0 WINS: 0 . 0 . 0 . 0 . 0	

Step 2: Configure the Laptop

a. Configure the Laptop to access the wireless network

Click on the Laptop icon on the Packet Tracer Logical workspace and in the Laptop configuration windows select the **Physical** tab.

In the Physical tab you will need to remove the Ethernet copper module and replace it with the Wireless WPC300N module.


To do this, you first power the Laptop off by clicking the power button on the side of the laptop. Then remove the currently installed Ethernet copper module by clicking on the module on the side of the laptop and dragging it to the **MODULES** pane on the left of the Laptop window. Then install the Wireless WPC300N module by clicking on it in the **MODULES** pane and dragging it to the empty module port on the side of the laptop. Power the laptop back on by clicking on the Laptop power button again.

With the wireless module installed, the next task is to connect the laptop to the wireless network.

Click on the **Desktop** tab at the top of the Laptop configuration window and select the **PC Wireless** icon.

Once the Wireless-N Notebook Adapter settings are visible, select the **Connect** tab. The wireless network "HomeNetwork" should be visible in the list of wireless networks as shown in the figure.

Select the network, and click on the **Connect** tab found below the **Site Information**.



Step 3: Configure the PC


a. Configure the PC for the wired network

Click on the PC icon on the Packet Tracer Logical workspace and select the **Desktop** tab and then the **IP Configuration** icon.

In the IP Configuration window, select the **DCHP** radio button as shown in the figure so that the PC will use DCHP to receive an IPv4 address from the Wireless router. Close the IP Configuration window.

PC		—
Physical Config Desktop	ttributes Software/Services	
IP Configuration		x
IP Configuration		
DHCP	⊖ Static	
IP Address	192.168.0.102	
Subnet Mask	255.255.255.0	
Default Gateway	192.168.0.1	
DNS Server	0.0.0.0	

Click on the Command Prompt icon. Verify the PC has received an IPv4 address by issuing the ipconfig /all command from the Command as shown in the figure. The PC should receive an IPv4 address in the 192.168.0.x range.



Step 4: Configure the Internet cloud

a. Install network modules if necessary

Click on the Internet Cloud icon on the Packet Tracer Logical workspace and then click on the Physical tab. The cloud device will need two modules if they are not already installed. The PT-CLOUD-NM-1CX which is for the cable modem service connection and the PT-CLOUD-NM-1CFE which is for a copper Ethernet cable connection. If these modules are missing, power off the physical cloud devices by clicking on the power button and drag each module to an empty module port on the device and then power the device back on.

b. Identify the From and To Ports

Click on the **Config** tab in the Cloud device window. In the left pane click on **Cable** under **CONNECTIONS**. In the first drop down box choose Coaxial and in the second drop down box choose Ethernet then click the **Add** button to add these as the From Port and To Port as shown in the figure.

Ŗ	Internet									\times		
	Physical Confi	g	Attributes									
	GLOBAL	\sim				Cable						
	Settings		Coaxial7			✓ <->	Ethernet6		•			
	TV Settings CONNECTIONS		Port				Port					
	Frame Relay		From Port	To Port						1		
	DSL		Coaxial7	Ethernet6								
	Cable		Country	Eulenieto								
	INTERFACE											
	Modem4 Modem5											
	Ethernet6											
	Coaxial7											
							-			1		
		5			Add		Remove					
	L	Ţ										
] Тор											
	1 lob											

d. Identify the type of provider

While still in the **Config** tab click Ethernet under **INTERFACE** in the left pane. In the Ethernet configuration window select **Cable** as the Provider Network as shown in the figure.

Physical Config Attributes GLOBAL Attributes Settings Provider Network TV Settings ONNECTIONS Frame Relay Frame Relay	
Settings Provider Network Connections Connections Connections Connections	
Settings Provider Network Connections Connections Connections Connections	
TV Settings CONNECTIONS	
Frame Relay	
DSL	
Cable	
INTERFACE	
Modem4 Modem5	
Ethernet6	
Coaxial7	
✓	
Птор	

Step 5: Configure the Cisco.com server

a. Configure the Cisco.com server as a DHCP server

Click on the Cisco.com server icon on the Packet Tracer Logical workspace and select the **Services** tab. Select **DHCP** from the **SERVICES** list in the left pane.

In the DHCP configuration window, configure a DHCP as shown in the figure with the following settings.

- Click **On** to turn the DCHP service on
- Pool name: DHCPpool
- Default Gateway: 208.67.220.220
- DNS Server: 208.67.220.220
- Starting IP Address: 208.67.220.1
- Subnet Mask 255.255.255.0
- Maximum number of Users: 50

Click Add to add the pool

🤻 Cisco.com											-		Х
Physical Config	Se	ervices Des	ctop Attrib	outes Software/	Service	s							
SERVICES	\sim					DF	ICP						
HTTP								~		~			-
DHCP		Interface		FastEthernet0 Service			•	On	0 0	ff			
DHCPv6		Pool Name		DHCPpool									1
TFTP													1
DNS		Default Gatew	ау	208.67.220.220									
SYSLOG		DNS Server		208.67.220.200									1
AAA		Start IP Addre		208		0		0		0			i
NTP		Start IF Addre		200				255					
EMAIL		Subnet Mask:		255		255							
FTP		Maximum numb	er of Users :							50	50		
IoE												-	
VM Management		TFTP Server:		0.0.0								1	
				Add		S	ave		Remove				
			ool me	Default Gateway		DNS Server	Start IP Address	;	Subnet Mask	Max User		TP rver	
		DHCPpool		208.67.220.220	208.6	7.220.200	208.0.0.0		255.255.255.0	50	0.0.0.0		

b. Configure the Cisco.com server as a DNS server to provide domain name to IPv4 address resolution.
 Still in the Services tab, select DNS from the SERVICES listed in the left pane.

Configure the DNS service using the following settings as shown in the figure.

- Click **On** to turn the DNS service on
- Name: Cisco.com
- Type: A Record
- Address: 208.67.220.220

Click Add to add the DNS service settings

R	Cisco.com										-		×
	Physical Config	Services	Desktop	Attributes	Softwar	e/Services							
	SERVICES						DNS						
	HTTP DHCP	DNS Ser	vice			On			⊖ off				
	DHCPv6 TFTP	Resourc	e Records	_									
	DNS	Name		4	Cisco.com				Туре	A Record		•	·
	SYSLOG AAA	Address	208.67.220	0.220									
	NTP			Add	Save			Remove					
	EMAIL FTP		No.		Name			Туре		Detail			
	IoE	0	c	cisco.com			A Record		208.6	7.220.220			
	VM Management	·											

c. Configure the Cisco.com server Global settings.

Select the **Config** tab. Click on **Settings** in left pane. Configure the Global settings of the server as follows:

- Select Static
- Gateway: 208.67.220.1
- DNS Server: 208.67.220.220

ę	Cisco.co	m							_	×
	Physical	Config	Se	ervices	Desktop	Attributes	Software/Services			
	GLC	BAL	\wedge					Global Settings		
		thm Settings Display Name Cisco.com								
	INTER	RFACE		Gatew	ay/DNS IPv4					
	FastEth	nernet0			HCP					
				St	atic					
				Gatew	vay 208.6	57.220.1				
				DNS S	erver 208.	57.220.220				

d. Configure the Cisco.com server FastEthernet0 Interface settings.

Click on **FastEthernet** in left pane of the **Config** tab Configure the FastEthernet Interface settings of the server as follows:

- Select Static under IP Configuration
- IP Address: 208.67.220.220
- Subnet Mask: 255.255.255.0

Cisco.com	-	\times
Physical Config	Services Desktop Attributes Software/Services	
GLOBAL Settings Algorithm Settings INTERFACE FastEthernet0	FastEthernet0 Port Status Bandwidth Duplex MAC Address IP Configuration O DHCP Static	0
	IP Address 208.67.220.220 Subnet Mask 255.255.0 IPv6 Configuration 0 O DHCP 0 Auto Config 0 Static 1 IPv6 Address 1 Link Local Address: FE80::210: 11FF:FE0D:38 1D	

Part 3: Verify Connectivity

Step 1: Refresh the IPv4 settings on the PC

a) Verify that the PC is receiving IPv4 configuration information from DHCP.

Click on the **PC** on the Packet Tracer Logical workspace and then the select the **Desktop** tab of the PC configuration window.

Click on the **Command Prompt** icon

In the command prompt refresh the IP settings by issuing the commands **ipconfig /release** and then **ipconfig /renew.** The output should show that the PC has an IP address in the 192.168.0.x range, a subnet mask, a Default Gateway, and DNS server address as shown in the figure.

R PC	_	×
Physical Config Desktop Attributes Software/Services		
Command Prompt		x
Packet Tracer PC Command Line 1.0		
C:\>ipconfig /release		
IP Address 0.0.0.0 Subnet Mask 0.0.0.0		
Default Gateway: 0.0.0.0 DNS Server 0.0.0.0		
C:\>ipconfig /renew		
IP Address: 192.168.0.101 Subnet Mask: 255.255.255.0		
Default Gateway 192.168.0.1 DNS Server		
c:\>		

b) Test connectivity to the Cisco.com server from the PC

From the command prompt issuing the command **ping Cisco.com.** It may take a few seconds for the ping to return. Four replies should be received as shown in the figure.

hysical Config Desktop	Attributes Software/Services	
Command Prompt		X
Packet Tracer PC Command	Line 1.0	
C:\>ipconfig /release		
IP Address		
Subnet Mask		
Default Gateway DNS Server		
DNS Server		
C:\>ipconfig /renew		
	. 100 100 0 101	
	: 192.168.0.101 : 255.255.255.0	
Default Gateway	: 192.168.0.1	
DNS Server	208.67.220.220	
C:\≻ping Cisco.com		
Pinging 208.67.220.220 wi	th 32 bytes of data:	
Reply from 208 67 220 220): bytes=32 time=1ms TTL=127	
): bytes=32 time=1ms TTL=127	
): bytes=32 time=2ms TTL=127	
Reply from 208.67.220.220): bytes=32 time=1ms TTL=127	
Ping statistics for 208.6	57.220.220:	
	eceived = 4, Lost = 0 (0% loss),	
	imes in milli-seconds:	
	m - 2ms, Average - ims	
Approximate round trip to Minimum = 1ms, Maximu		

Part 4: Save the File and Close Packet Tracer

Step 1: Save the File as a Packet Tracer Activity File (*.pkt)

To save the completed network click on **File** in the Packet Tracer Menu bar and then select **Save As...** from the dropdown menu. In the the Save File window choose a directory to save the file to and give the file an appropriate file name. The Save as type defaults to Packet Tracer Activity File (*.pkt). Click **Save** to save the file.

💘 Save File						×
← → ✓ ↑ 📙 → My Packet Tracer Files			ٽ ~	Search My Packe	t Tracer Files	Q
Organize 👻 New folder						?
> 📌 Quick access	Name	^	Date modified	Туре	Size	
> 🔜 Desktop		No items i	match your search.			
	<					>
File name: My Packet Tracer Activity.pkt						~
Save as type: Packet Tracer Activity File (*.pkt)						~
∧ Hide Folders				Save	Cance	

Step 2: Close Packet Tracer

To close Packet Tracer you can either click the "X" in the top right corner of the Packet Tracer window, or click on **Exit** in the File drop down menu.